


## Cheese Slicer Build Instructions



### Board Layout:

Board should be at least  $5/8$ " thick. I recommend making it  $5\ 3/4$ " x  $9\ 1/2$ " in size.

Place the board good side up on your work surface. The hole for the hardware will be  $1/4$ " diameter drilled  $3/8$ " from the top of the board and 5" from the right front of the board. Drill at least  $3\ 7/8$ " deep.

Note: Some standard length bits may not be long enough to drill this depth. I recommend using a bit that is 6" or longer.

The saw kerf will be 3" from the right side of the board. Cut a  $3/8$ " deep slot at an angle that is  $1/4$ " deep at the front of the board and deep enough to clear the hole toward the back of the board. I use a thin kerf blade, but you could also use a standard kerf blade for this project.

If your board is thicker, the hole should be just as deep from the face of the board as it is on the any other material.

